



LTZ-KFX400
Air Scoop Instructions

1. Remove uppermost rearward 6mm bolt that mounts front fender and bracket assembly to frame.
2. Place OMF scoop over the stock plastic radiator louver assembly making sure the lower tab of the scoop is **BEHIND** at the bottom of the louver assembly.
3. Replace the bolt removed in step one with a new supplied bolt along with a flat washer and lock washer and tighten to a semi-snug fitment.
4. Align the top front of the scoop with the hole in the stock frame gusset and install supplied fasteners and tighten snug.
5. Tighten the fasteners installed in step 3 until snug.
6. Mark the stock plastic radiator louver at the 3 holes in the scoop. Two are along the side and one is at the bottom of the louvers.
7. Remove the scoop and radiator louver and drill the louver assembly with a 1/4" drill at the locations marked in step 6.
8. Reassemble using supplied fasteners making sure that the lower bolt in the louver is installed from the front.